



Proto Buddy

Sweet little breadboard set up



This one is pretty simple...

Mount your DC socket.

Mount your jacks -
TRS goes on the input,
mono on the output.

Mount your bypass toggle
switch - DPDT ON-ON.

Solder in the solid core
wires on the two outer
sets of V-G pads.

Solder in your flying leads.

Solder the battery snap
(if you're adding one)
to the +/- pads next to the
input jack.

Stick your breadboard to
the PCB.

Insert the solid core outer
wires into the +/- points of
the breadboard.

GO!

Your battery will be
disconnected when there's
no input jack inserted.

